

MagicPak[®] Banner Case Latch Replacement

Insert the latch pin into the hole in the lid, with the logo side of the latch facing away from the lid opening.

1



Once the pin has been inserted and the latch is sitting properly in place, drive the pin back through the latch and secure it by extending the pin through the hole on the opposite side of the molded ridge.

2



When complete, the pin will extend through the latch and protrude through both holes on the lid.

3



*Any questions or concerns call:
1-800-891-1869*